

HOW TO USE


HOW TO USE VIDEO




WWW.XTENSITY.COM

1. Choose cup that fits the erected penis.

Better with too small cup than too big



2. Attach sleeve



Use slot to support cup

Adjust



Align top

& sleeve circle to fit the cup edge

Roll up sleeve




Into slot

Do not pull up

Roll up sleeve

Prevent roll-down with finger

3. Pull back foreskin



1. Pull back

Not retracted may pinch

Insert erected penis



2. Place cup (foreskin held back)

3. Initiate roll down with finger

Roll down sleeve



4. Push out excessive air



Push out air if air between cup & penis

Insert cup, push & adjust speed

No air between cup & penis improve vacuum lock effect & stimulation. If air pocket(s) occur during use push out the air.

Recommended duration of maximum 10 minutes

Make sure one way valve does not fall off during use

Do not use near or in water.

Read manual before use. Not for internal use. Do not use if bleeding disorder. Stop using if discomfort or pain. Consult physician before use if medical condition.



AFTER USE

1. Push  to turn "OFF" & disconnect cup from massage gun



Do not pull cup off penis before sleeve rolled down or vacuum pressure released

2. Roll down sleeve from top to release




- 3 After rolling down sleeve & releasing pressure, pull off cup
- 2 Remove one-way valve to release pressure
- 1 Roll sleeve off cup

3. Cleaning

Turn "**OFF**" massager before cleaning. Do not submerge the massage gun in water during cleaning, or get water inside the product itself.

Cleaning of massager

Clean with antibacterial damp cloth. Ensure product is dry before use.



NO WATER
on massager

Cleaning of cup & sleeve

Only cup, one way-valve and sleeve can be washed with regular water, soap and dried with a cloth. Detach from massage gun before cleaning.

